



DUCT5

5' de tuyau isolé flexible additionnel pour l'évent par gravité du Caméléon et du Topaz

La trousse actuelle fournie 5 pieds additionnels de tuyau isolé flexible. Référez-vous aux instructions d'installation de la trousse d'évent par gravité (VCT) et respectez la longueur totale maximale de 15 pieds de tuyau.

MISE EN GARDE: Il est défendu d'utiliser une pièce de substitution pour l'une ou l'autre des composantes de cette trousse. Les pièces d'origine RSF possèdent les dégagements appropriés dont le respect intégral est essentiel pour votre sécurité.

INSTALLATION

Installez votre trousse d'évent par gravité (VCT) tel qu'expliqué dans les instructions. Pour allonger le tuyau isolé flexible, faites tel que décrit ci-après :

1. Insérez la bague de raccordement à moitié dans l'extrémité d'un des tuyaux isolés flexibles. En utilisant trois des vis auto-taraudeuses et trois des rondelles fournies, vissez à travers le tuyau isolé flexible pour l'attacher à la bague de raccordement.
 2. Insérez l'autre moitié de la bague de raccordement dans l'extrémité de l'autre tuyau isolé flexible. En utilisant les trois vis auto-taraudeuses et les trois rondelles restantes, vissez à travers le tuyau isolé flexible pour l'attacher à la bague de raccordement.
-



DUCT5

Additional 5' insulated flexible duct for gravity vent for Chameleon and Topaz

The current kit provides 5 additional feet of insulated flexible duct to be used with the gravity vent kit (VCT). Please refer to the installation instructions of the gravity vent (VCT) and respect the maximum duct length of 15 feet in total.

WARNING: No substitution of any of these parts is allowed. These genuine RSF parts have the correct clearances. These clearances must be maintained for your safety.

INSTALLATION

Install you gravity vent as explained in the gravity vent kit (VCT). To extend the length of the duct do the following:

1. Insert the connector sleeve half-way into the end of one of the insulated flexible duct. Using three of the self- tapping screws with three flat washers provided, screw through the insulated flexible duct to attach it to the connector sleeve.
2. Insert the other half of the connector sleeve into the end of the other insulated flexible duct. Using the remaining self-tapping screws and flat washers provided, screw through the insulated flexible duct to attach it to the connector sleeve.

Liste de contrôle / Check List:

- 1 Bague de raccordement / Connector sleeve (13.DUCT5.1.CT)
- 1 Tuyau flexible isolé / Insulated flexible duct (13.DUCT5.2.CT)
- 1 Sac contenant 6 vis auto-taraudeuses #8-3/4" (901015) et 6 rondelles 3/4" (904005)
Bag containing 6 self-tapping screws and 6 flat washers
- Notice d'installation et liste de contrôle / Instructions and check list

INITIALES
INITIALS